

Solo bar IR codes

Commands on the Solo bar remote control

Function	Decimal	Hex	Comments
Standby	19-12	13-0C	Toggle standby ON/OFF
Mute	19-13	13-0D	Mute
Increase volume	19-16	13-10	Volume Up
Decrease volume	19-17	13-11	Volume Down
Toggle ALC	19-70	13-46	Auto Loudness Control
Mode	19-32	13-20	Select Audio Mode
Select next input	19-41	13-29	Input Up
Select previous input	19-42	13-2A	Input Down
Navigate Up	19-86	13-56	Navigate Up
Navigate Down	19-85	13-55	Navigate Down
Navigate Left	19-81	13-51	Navigate Left
Navigate Right	19-80	13-50	Navigate Right
OK	19-87	13-57	OK/Enter
Enter system menu	19-82	13-52	Menu

Additional commands (not on the Solo bar remote)

Key Name	Decimal	Hex	Comments
Power On	19-123	13-7B	If the soundbar is OFF, turn it ON
Power Off	19-124	13-7C	If the soundbar is ON, turn it OFF
Select BT	19-11	13-0B	Switch directly to the BT input
Select HDMI1	19-00	13-00	Switch directly to the HDMI1 input
Select HDMI2	19-01	13-01	Switch directly to the HDMI2 input
Select HDMI3	19-02	13-02	Switch directly to the HDMI3 input
Select HDMI4	19-04	13-04	Switch directly to the HDMI4 input
Select COAX	19-05	13-05	Switch directly to the COAX input
Select OPTICAL	19-06	13-06	Switch directly to the OPTICAL input
Select AUX	19-07	13-07	Switch directly to the AUX input