

P429 Software Release Notes

To update:

- Optional: Connect the amplifier to RS232 or Network control program and read current software version
- Ensure the update file is named P429.hex and copy to the root directory of a USB drive
- Power off the amplifier
- Insert the USB drive into the rear socket
- Power on the amplifier
- The software upgrade will start and the front panel LED will flash green during this step
- Once the upgrade is complete, the front panel LED will turn solid red
- Power off the P429
- Remove the USB drive
- Power on the unit
- Optional: Reconnect RS232 or network controller and read the new software version

Version	Fix list
1.28	Minor bug fixes and stability improvements
1.27	Added the ability to enable/disable signal sense auto shutdown
1.25	The front panel status LED indicates mute when any channel is muted and it indicates unmute when all channels are unmuted
1.24	Improved the audio detect feature, to avoid invalid restarts while in standby
1.22	Fan delay counter restarted when power relay closed if fan percent is set to slow
1.20	Fixed the previous power state sequence, which caused the unit to sometime turn on in the OFF state following a factory reset/reboot