



Custom installation guide – Solo

Later versions will be made available on the Arcam dealer extranet at:

www.arcam.co.uk




Introduction

Solo is an extremely flexible CI product and will allow for a very simple two-zone setup with independent volume control for Zone 1 and Zone 2.

Solo will require a remote pick-up device such as a Xantech Dinky Link located within Zone 2 and a Power amplifier such as the signal sensing Arcam P80 to complete the system.

The below diagram demonstrates the implementation of a external power supply for a Xantech Dinky Link although the same wiring scheme will be maintained for many other IR pick-up devices commonly available.




Solo also has the ability to provide a **+12v trigger** for control of ancillary devices such as power amplifier in the Second Zone; the +12v control is active when the Solo is not in Off or Standby modes.


CI Guide Solo V1 Page 2 of 3

Connector wiring diagrams


Solo remote control input



Solo remote output.



Solo trigger output



CI Guide Solo V1 Page 3 of 3